

EN - english



**Instructions for installation and operation**

**Compressed air refrigeration chiller  
BEKOBLIZZ® LC 480-720**

---

Dear customer,

Thank you for deciding in favour of the BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller. Please read these installation and operating instructions carefully before mounting and starting up the BEKOBLIZZ® LC 480-720 and follow our directions. Perfect functioning of the BEKOBLIZZ® LC 480-720 and thus reliable compressed-air drying can only be guaranteed when the provisions and notes stipulated here are strictly adhered to.

---

## Contents

1	Name plate	5
2	Safety instructions	5
2.1	Safety pictograms in accordance with DIN 4844	6
2.2	Signal words in accordance with ANSI	8
2.3	Overview of the safety instructions	8
3	Proper use	11
4	Exclusion from a field of application	11
5	Operating instructions in accordance with the 97/23/EC Pressure Equipment Directive	12
6	Transport	13
7	Storage	13
8	Installation	14
8.1	Place of installation	14
8.2	Installation plan	15
8.3	Correction factors	16
8.4	Connection to the compressed-air system	17
8.5	Connection to the cooling-water network	17
8.6	Minimum cooling-water requirements:	18
8.7	Electrical connections	19
8.8	Condensate drain	20
9	Start-up	20
9.1	Preliminary stages	20
9.2	Initial start-up	21
9.3	Start-up and shut down	22
10	Technical data	23
10.1	Technical data BEKOBLIZZ LC 480-720 3/400/50	23
10.2	Technical data BEKOBLIZZ LC 480-720 3/460/60	24
11	Technical description	25
11.1	Control panel	25
11.2	Functional description	25
11.3	Flow chart (air-cooled)	26
11.4	Flow chart (water-cooled)	26
11.5	Refrigerating compressor	27
11.6	Condenser (air-cooled)	27
11.7	Condenser (water-cooled)	27
11.8	Cooling-water regulating valve	27
11.9	Filter dryer	27
11.10	Capillary tube	27
11.11	Air-to-refrigerant heat exchanger	27
11.12	Condensate separator	27
11.13	Hot-gas bypass valve	27
11.14	Refrigerant pressure switches LPS – HPS	28
11.15	Compressor crankcase heater	28
11.16	DMC 24 electronics (control unit compressed-air chiller)	29
11.16.1	Switching the chiller on	29
11.16.2	Switching the chiller off	29
11.16.3	Indication of the operating parameters – Info menu	30
11.16.4	Indication of a service warning	31
11.16.5	Alarm indication	32
11.16.6	Display of the alarm memory – log menu	33
11.16.7	Control of the chiller via remote control	33
11.16.8	Operation of the potential-free failure/alarm contact	33
11.16.9	Connection to a serial line	33
11.16.10	Operating parameters – setup menu	34
11.17	Electronically level-controlled BEKOMAT condensate drain	35
12	Maintenance, troubleshooting, spare parts and dismantling	36
12.1	Checks and maintenance	36

---

12.2	Troubleshooting	37
12.3	Recommended spare parts	42
12.4	Maintenance works at the refrigeration cycle	43
12.5	Dismantling the chiller	43
13	Appendices	44
13.1	Chiller dimensions	44
13.1.1	Dimensions BEKOBLIZZ LC 480-720	44
13.2	Exploded diagrams	45
13.2.1	Components of the exploded diagrams	45
13.2.2	Exploded diagram BEKOBLIZZ LC 480-720	46
13.3	Electric diagrams	47
13.3.1	Electric diagrams – list of components	47
13.3.2	Electric diagrams BEKOBLIZZ LC 480-720 - Electronic control unit DMC 24 Sheet 1/3	48
13.3.3	Electric diagrams BEKOBLIZZ LC 480-720 - Electronic control unit DMC 24 Sheet 2/3	49
13.3.4	Electric diagrams BEKOBLIZZ LC 480-720 - Electronic control unit DMC 24 Sheet 3/3	50
14	EC Declaration of Conformity	51

## 1 Name plate

The name plate is on the back of the chiller and comprises all primary data of the device. Always refer to these data when contacting the manufacturer or the sales department.

All guarantee claims will expire in the event that the name plate is modified or removed.

The chiller model printed on the nameplate includes one or more suffixes that specify one or more features of chiller.

Explanation of 1st suffix for power supply requirements :

1st SUFFIX	DESCRIPTION OF FEATURE
none	3/400/50
-R	3/460/60
-S	3/230/60 (with internal autotransformer)
-F	3/380/60 (with internal autotransformer)
-T	3/690/60 (with internal autotransformer)

Explanation of 2nd suffix for cooling requirements :

2nd SUFFIX	DESCRIPTION OF FEATURE
/ AC	Air cooled
/ WC	Fresh water cooled

Explanation of (eventual) 3rd suffix for special feature :

3rd SUFFIX	DESCRIPTION OF FEATURE
-TAC	Anti corrosion treatment
-SP	Special feature
-OF	chiller oil free

Examples :      BEKOBLIZZ LC480-R /AC      →      BB LC480, 3/460/60, Air cooled  
                          BEKOBLIZZ LC600 /WC      →      BB LC600 3/400/50, Water cooled  
                          BEKOBLIZZ LC720-T /AC -TAC→      BB LC720 3/690/60, Air cooled, Anti corrosion treatment

## 2 Safety instructions



### Please check whether or not these instructions correspond to the device type.

Please adhere to all advice given in these operating instructions. They include essential information which must be observed during installation, operation and maintenance. Therefore, it must be ensured that these operating instructions are read by the fitter and the responsible operator / certified skilled personnel prior to installation, start-up and maintenance.

The operating instructions must be accessible at all times at the place of application of the BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller.

In addition to these operating instructions, local and national regulations need to be observed, where required.

Ensure that operation of the BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller only takes place within the permissible limit values indicated on the name plate. Any deviation from these limit values involves a risk for persons and for the material, and may result in malfunction or a breakdown.

After installing the device correctly and in accordance with the instructions in this manual, the chiller is ready to operate, further settings are not required. Operation is fully automatic and maintenance is limited to several examinations and cleaning measures which are described in the following chapters.

This manual must be available at all times for future reference and is a constituent part of the chiller.

If you have any queries regarding these installation and operating instructions, please contact BEKO TECHNOLOGIES GMBH.

### 2.1 Safety pictograms in accordance with DIN 4844



Observe operating instructions



General danger symbol



Supply voltage



Danger: component or system under pressure



Hot surfaces



Non-breathable air



Do not use water to extinguish the fire



Do not operate with open cover (housing)



Maintenance works or controlling measures must only be carried out by qualified personnel <sup>1</sup>



Do not smoke



Note



Connection point compressed-air inlet




Connection point compressed-air outlet



Connection point condensate drain



Connection point cooling-water inlet (water-cooled)



Connection point cooling-water outlet (water-cooled)

<sup>1</sup> Certified skilled personnel are persons who are authorised by the manufacturer, with experience and technical training, who are well-grounded in the respective provisions and laws and capable of carrying out the required works and of identifying and avoiding any risks during the machine transport, installation, operation and maintenance. Qualified and authorised operators are persons who are instructed by the manufacturer regarding the handling of the refrigeration system, with experience and technical training, and who are well-grounded in the respective provisions and laws.



Works can be carried out by the operator of the plant, provided that they are skilled accordingly <sup>2</sup>.

**NOTE:** Text that contains important specifications to be considered – does not refer to safety precautions.



The device was carefully designed with particular attention paid to environmental protection:

- CFC-free refrigerants
- CFC-free insulation material
- Energy-saving design
- Limited acoustic emissions
- Chiller and packaging comprise reusable materials

This symbol advises the user to observe the environmental aspects and comply with the recommendations connected with this symbol.

---

<sup>2</sup> Certified skilled personnel are persons who are authorised by the manufacturer, with experience and technical training, who are well-grounded in the respective provisions and laws and capable of carrying out the required works and of identifying and avoiding any risks during the machine transport, installation, operation and maintenance. Qualified and authorised operators are persons who are instructed by the manufacturer regarding the handling of the refrigeration system, with experience and technical training, and who are well-grounded in the respective provisions and laws.

### 2.2 Signal words in accordance with ANSI

<b>Danger!</b>	Imminent hazard Consequences of non-observance: serious injury or death
<b>Warning!</b>	Potential hazard Consequences of non-observance: possible serious injury or death
<b>Caution!</b>	Imminent hazard Consequences of non-observance: possible injury or property damage
<b>Notice!</b>	Potential hazard Consequences of non-observance: possible injury or property damage
<b>Important!</b>	Additional advice, info, hints Consequences of non-observance: disadvantages during operation and maintenance, no danger

### 2.3 Overview of the safety instructions



#### **Certified skilled personnel**

Installation works must exclusively be carried out by authorised and qualified skilled personnel. Prior to undertaking any measures on the BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller, the certified skilled personnel shall read up on the device by carefully studying the operating instructions. The operator is responsible for the adherence to these provisions. The respective directives in force apply to the qualification and expertise of the certified skilled personnel.

For safe operation, the device must only be installed and operated in accordance with the indications in the operating instructions. In addition, the national and operational statutory provisions and safety regulations, as well as the accident prevention regulations required for the respective case of application, need to be observed during employment. This applies accordingly when accessories are used.



#### **Danger!**

##### **Compressed air!**

**Risk of serious injury or death through contact with quickly or suddenly escaping compressed air or through bursting and/or unsecured plant components.**

Compressed air is a highly dangerous energy source.

Never work on the chiller when the system is under pressure.

Never direct the compressed-air outlet or condensate drain hoses at persons.

The user is responsible for the proper installation of the chiller. Non-observance of the instructions in the "Installation" chapter leads to the expiration of the guarantee. Improper installation may result in dangerous situations for the personnel and/or the device.



#### **Danger!**

##### **Supply voltage!**

**Contact with non-insulated parts carrying supply voltage involves the risk of an electric shock resulting in injuries and death.**

Only qualified and skilled personnel are authorised to run electrically-operated devices. Prior to undertaking maintenance measures at the device, the following requirements must be met:

Make sure that the power supply is switched off and that the device is off and marked for maintenance measures. Please also ensure that the power supply cannot be re-established during the works.



#### **Caution!**

##### **Refrigerant!**

**The compressed-air refrigeration chiller uses HFC-containing refrigerants as a coolant.**

Please observe the corresponding paragraph entitled "Maintenance works at the refrigeration cycle".

**Warning!****Refrigerant leak!**

**A refrigerant leak involves the danger of serious injury and damage to the environment.**



The BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller contains fluorinated greenhouse gas/refrigerant.

Installation, repair and maintenance works at the refrigeration system must only be carried out by certified skilled personnel (specialists). A certification in accordance with EC regulation 303/2008 must be available.



The requirements of the EC 842/2006 directive must be met under all circumstances.

Please refer to the indications on the name plate as regards the type and amount of refrigerant.



Comply with the following protective measures and rules of conduct:



- **Storage:** Keep the container tightly closed. Keep it in a cool and dry place. Protect it against heat and direct sunlight. Keep it away from ignition sources.
- **Handling:** Take measures against electrostatic charging. Ensure good ventilation/suction at the workplace. Check fittings, connections and ducts for tightness. Do not inhale the gas. Avoid contact with the eyes or the skin.
- Prior to carrying out works on refrigerant-carrying parts, remove the refrigerant to such an extent that safe working is possible.
- Do not eat, drink or smoke during work. Keep out of the reach of children.
- **Breathing protection:** ambient-air-independent respirator (at high concentrations).
- **Eye protection:** sealing goggles.
- **Hand protection:** protective gloves (e.g. made of leather).
- **Personal protection:** protective clothing.
- **Skin protection:** use protective cream.

In addition, the safety data sheet for the refrigerant needs to be observed!

**Caution!****Hot surfaces!**

**During operation, several components can reach surface temperatures of more than +60°C. There is the risk of burns.**

All components concerned are installed inside of the closed housing. The housing must only be opened by certified skilled personnel <sup>3</sup>.

**Caution!****Improper use!**

The device is intended for the separation of water in compressed air. The dried compressed air cannot be used for breathing-air purposes and is not suitable for the direct contact with food.

This chiller is not suitable for the treatment of contaminated air or of air containing solids.

<sup>3</sup> Certified skilled personnel are persons who are authorised by the manufacturer, with experience and technical training, who are well-grounded in the respective provisions and laws and capable of carrying out the required works and of identifying and avoiding any risks during the machine transport, installation, operation and maintenance. Qualified and authorised operators are persons who are instructed by the manufacturer regarding the handling of the refrigeration system, with experience and technical training, and who are well-grounded in the respective provisions and laws.



### Note!

#### Contaminated intake air!

In the event that the intake air is strongly contaminated (ISO 8573.1 class 3.-3 or poorer quality), we recommend the additional installation of a prefilter (e.g. CLEARPOINT F040), to avoid clogging of the heat exchanger.



### Caution!

#### Heating-up through fire!

**In the event of a heating-up through fire, the containers and pipes of the refrigerant system can burst.**



In this case, please proceed as follows:

Switch off the refrigeration plant.

Switch off the mechanical ventilation of the machinery compartment.

Use ambient-air-independent respirators.

Containers and plants which are filled with refrigerant can burst violently in the event of fire.

The refrigerants themselves are incombustible, but they are degraded to very toxic products at high temperatures.

Remove the container/plant from the fire zone, as there is the risk of bursting!

Cool down containers and bottles via a directed water jet from a safe position.

In the event of fire, please use an approved fire extinguisher. Water is not a suitable agent to extinguish an electrical fire.

This must only be carried out by persons who are trained and informed about the hazards emanating from the product.



### Caution!

#### Unauthorised intervention!

**Unauthorised interventions may endanger persons and plants and lead to malfunction.**

Unauthorised interventions, modification and abuse of the pressure devices are prohibited.

The removal of sealings and leadings at safety devices is prohibited.

Operators of the devices must observe the local and national pressure equipment regulations in the country of installation.



### Note!

#### Ambient conditions!

In the event that the chiller is not installed under suitable ambient conditions, the ability of the device to condense refrigerant gas is impaired. This can result in a higher load of the refrigerating compressor, and in a loss of efficiency and performance of the chiller.

This in turn leads to overheated condenser fan motors, to malfunction of electric components and to a breakdown of the chiller. Failures of this type will affect warranty considerations.

Do not install the chiller in an environment in which chemicals with a corrosive effect, explosive gases, toxic gases, evaporation heat, high ambient temperatures or extreme dust and dirt can be found.

### 3 Proper use

This chiller was designed, manufactured and tested to separate the moisture which normally exists in compressed air. Any other use is considered improper.

The manufacturer shall not be liable for problems occurring as a consequence of improper use. The user alone is responsible for any damage resulting from that.

Furthermore, the correct use includes the compliance with the installation instructions, in particular in respect of:

- The voltage and frequency of the main voltage supply.
- The pressure, temperature and flow rate of the inlet air.
- The pressure, temperature and cooling-water throughput (water-cooled).
- The ambient temperature.

When delivered, the chiller is tested and fully assembled. The customer only needs to connect the device to the system in accordance with the instructions in the following chapters.

### 4 Exclusion from a field of application



**Note!**  
**Improper use!**



The device is intended for the separation of water in compressed air. The dried compressed air cannot be used for breathing-air purposes and is not suitable for the direct contact with food.  
This chiller is not suitable for the treatment of contaminated air or of air containing solids.

## **5 Operating instructions in accordance with the 97/23/EC Pressure Equipment Directive**

The BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller contains pressure equipment in the sense of the 97/23/EC Pressure Equipment Directive. Therefore, the entire plant needs to be registered with the supervisory authority if required in accordance with the local regulations.

For the examination prior to the start-up and for periodic inspections, the national regulations need to be observed, such as the industrial safety regulation in the Federal Republic of Germany. In countries outside the EU, the respective regulations in force there need to be adhered to.

The proper use of pressure devices is the basic requirement for safe operation. As regards pressure devices, the following points need to be observed:

- The BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller must only be employed within the pressure and temperature range limits indicated by the manufacturer on the name plate.
- No welding must be carried out on the pressure parts.
- The BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller must neither be installed in insufficiently ventilated rooms nor near heat sources or inflammable substances.
- To avoid fractures resulting from material fatigue, the refrigeration chiller should not be exposed to vibrations during operation.
- The maximum operating pressure indicated by the manufacturer on the name plate must not be exceeded. It is the installer's responsibility to install the appropriate safety and control devices. Prior to the start-up of the BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller, the connected pressure generator (compressor etc.) must be set to the max. permissible operating pressure. The integrated safeguard needs to be checked by an approved inspection agency.
- The documents related to the BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller (manual, operating instructions, manufacturer's declaration etc.) must be kept safe for future reference.
- No objects whatsoever must be installed at or placed on the BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller and the connecting lines.
- Installation of the plant in frost-free places only.
- Operation of the plant is only permissible with fully closed and intact housing and cover panels. Operation of the plant with damaged housing/cover panels is prohibited.

## 6 Transport


Check the packaging for visible loss or damage. If no visible damage can be ascertained, place the unit in close proximity to the place of installation and unpack the device.

During this procedure, the chiller must always remain in an upright position. The components may be damaged when the unit is tilted or turned upside down.

Store the device in a dry environment and do not expose it to extreme weather conditions.

Handle with care. Strong shocks can cause irreparable damage.

## 7 Storage



Keep the device away from extreme weather conditions even when packaged.

Keep the chiller in an upright position, also while it is stored. Tilting the device or turning it upside down can cause irreparable damage to some components.

When the chiller is not in use, it can be stored in its packaging in a dust-free and protected place at a temperature of up to max. 50°C and at a specific humidity of max. 90%. If the storage period exceeds 12 months, you should contact the manufacturer.



The packaging material is recyclable. Dispose of the material in accordance with the directives and provisions in force in the country of destination

### 8 Installation

#### 8.1 Place of installation



**Note!**

**Ambient conditions!**

In the event that the chiller is not installed under suitable ambient conditions, the ability of the device to condense refrigerant gas is impaired. This can result in a higher load of the refrigerating compressor, and in a loss of efficiency and performance of the chiller.

This in turn leads to overheated condenser fan motors, to malfunction of electric components and to a breakdown of the chiller. Failures of this type will affect warranty considerations.

Do not install the chiller in an environment in which chemicals with a corrosive effect, explosive gases, toxic gases, evaporation heat, high ambient temperatures or extreme dust and dirt can be found.

**Minimum installation requirements:**

- Choose an area which is clean and dry, free from dust and protected against atmospheric disturbances.
- The load-bearing zone must be even, horizontal and able to bear the weight of the chiller.
- Minimum ambient temperature +1°C.
- Maximum ambient temperature +50°C.
- Ensure a proper cooling air replacement.
- Allow a sufficient clearance on each side of the chiller for proper ventilation and to facilitate maintenance operations. The chiller does not require attachment to the floor surface.




**Do not obstruct the ventilation grille (not even partially).**

Prevent any recirculation of the outgoing cooling air.

Protect the chiller against draughts.

8.2 Installation plan



Installation **type A** straight upstream of the application is recommended.

Installation **type B** is **NOT** recommended because of the low compressed air temperature there will be condensation outside of the pipes and vessel and the air will be rewarmed.



**Do not obstruct the ventilation grille (not even partially).**

Prevent any recirculation of the outgoing cooling air.

Protect the chiller against draughts.



**Note!**

**Contaminated intake air!**

In the event that the intake air is strongly contaminated (ISO 8573.1 class 3.-3 or poorer quality), we recommend the additional installation of a prefilter (e.g. CLEARPOINT F040), to avoid clogging of the heat exchanger.



## 8.4 Connection to the compressed-air system



### **Danger!** **Compressed air!**

All works must only be carried out by qualified skilled personnel.  
Never work on compressed-air systems which are under pressure.



The operator or the user must ensure that the chiller is never operated with a pressure exceeding the maximum pressure value indicated on the name plate.  
Exceeding the maximum operating pressure can be dangerous for the operator but also for the device.

The air temperature and the air flow at the inlet of the chiller must lie within the limit values indicated on the name plate. The connecting lines must be free from dust, iron rust, shards and other contaminations and correspond to the flow rate of the chiller. Should air with a very high temperature be treated, the installation of an aftercooler may be necessary. For the implementation of maintenance works, the installation of a bypass system is recommended.



### **Note!** **Pulsation and vibrations!**

Pulsations and vibrations must be eliminated from the compressed air and IN/OUT piping to avoid possible fatigue failure.  
Do not use the chiller to treat air containing corrosive substances for copper and its alloys..



### **CAUTION!**

During the piping of the chiller, the inlet and outlet connections need to be supported as is shown in the illustration.  
Non-observance will cause damage.



### **Note!** **Contaminated intake air!**

In the event that the intake air is strongly contaminated (ISO 8573.1 class 3.-3) or poorer quality, we recommend the additional installation of a prefilter (e.g. CLEARPOINT F040), to avoid clogging of the heat exchanger.

## 8.5 Connection to the cooling-water network



### **Danger!** **Compressed air and unqualified personnel!**

All works must only be carried out by qualified skilled personnel.  
Never work on compressed-air systems which are under pressure.



The user must ensure that the chiller is never operated with a pressure exceeding the nominal values.  
Possible overpressure can be dangerous for the operator but also for the device.

The temperature and the amount of cooling water need to correspond to the limit values indicated on the name plate. The cross-section of the connecting lines, which should preferably be flexible, must be free from dust, iron rust, shards and other contaminations. We recommend employing connecting lines (flexible hoses, vibration-inhibiting fittings etc.) which protect the chiller against possible vibrations in the pipework.



### **Note!** **Contaminated intake water!**

In the event that the intake water is strongly contaminated we recommend the additional installation of a prefilter (500 micron), to avoid clogging of the heat exchanger.

**8.6 Minimum cooling-water requirements:**

Temperature	15 ... 30°C (1)	HCO <sub>3</sub> / SO <sub>4</sub>	>1.0 mg/l or ppm
Pressure	3...10 bar(g) (2)	NH <sub>3</sub>	<2 mg/l or ppm
Delivery pressure	> 3 bar (2) (3)	Cl <sup>-</sup>	50 mg/l or ppm
Total hardness	6.0...15 dH°	Cl <sub>2</sub>	0.5 mg/l or ppm
PH	7.5...9.0	H <sub>2</sub> S	<0.05 mg/l or ppm
Conductivity	10...500 µS/cm	CO <sub>2</sub>	<5 mg/l or ppm
Residual solids	<30 mg/l or ppm	NO <sub>3</sub>	<100 mg/l or ppm
Saturation mark SI	-0.2 < 0 < 0.2	Fe	<0.2 mg/l or ppm
HCO <sub>3</sub>	70...300 mg/l or ppm	Al	<0.2 mg/l or ppm
SO <sub>4</sub> <sup>2-</sup>	<70 mg/l or ppm	Mn	<0.1 mg/l or ppm

- Note:
- (1) – Other temperatures upon request – check the data on the name plate.
  - (2) – Other pressures upon request – check the data on the name plate.
  - (3) – Pressure difference at the water connection of the chiller at maximum water flow. Other delivery pressures upon request.

**CAUTION!**

During the piping of the chiller, the inlet and outlet connections need to be supported as is shown in the illustration.

Non-observance will cause damage.

## 8.7 Electrical connections





### Danger! Supply voltage!

The connection to the electric mains should only be carried out by qualified skilled personnel and must correspond to the legal provisions in force in your region.

Prior to connecting the device, please check the name plate to avoid exceeding the indicated values. The voltage tolerance is +/- 10%.

The installer is responsible for supplying and installing the power cable. Be sure to provide the proper fuses or breakers based on the data information located on the nameplate.



A residual-current device (RCD) with  $I_{\Delta n}=0.03A$  is suggested. The cross-section of the power supply cables must correspond to the consumption of the chiller. In this respect, the ambient temperature, the cable laying conditions, the length of the cables and the requirements of the local electricity supplier need to be considered.



### CAUTION!

**Please observe the direction of rotation of the compressor!**

**In this system, the direction of rotation of the compressor is supervised by a reverse-phase protector (RPP).**

When this guard is triggered, the DMC24 goes into alarm mode (the alarm LED flashes  and the display of the DMC24 shows **OFF** and **Con**). In the event that the compressor does not run, the direction of rotation must be changed by interchanging two phases. These modifications must only be carried out by a qualified electrician.

**Do not by-pass the RPP protector: If the device is operated with the incorrect direction of rotation, the compressor will fail immediately. This will void the guarantee.**



### Danger! Supply voltage and missing earth connection!

Important: ensure that the plant is connected to earth.

Do not use plug adapters at the power plug.

Possible replacement of the power plug must only be carried out by a qualified electrician.

### 8.8 Condensate drain



**Danger!**

**Compressed air and condensate under pressure!**

The condensate is discharged at system pressure.  
The drain pipe needs to be secured.  
Never direct the condensate drain pipe at persons.

The chiller is delivered with an already integrated electronically level-controlled BEKOMAT condensate drain. Connect the condensate drain with a collection system or container by properly screwing it on. Do not connect the drain with pressure plants.



Do not discharge the condensate into the environment.  
The condensate accumulating in the chiller contains oil particles which were released into the air by the compressor.  
Dispose of the condensate in accordance with the local provisions.

It is advisable to install a water-oil separator, to which the total amount of condensate from the compressors, chillers, tanks, filters etc. is supplied.  
We recommend ÖWAMAT oil-water separators for dispersed compressor condensate and BEKOSPLIT emulsion-splitting plants for emulsified condensate.

## 9 Start-up

### 9.1 Preliminary stages



**Note!**

**Exceeding of the operating parameters!**

Ensure that the operating parameters comply with the nominal values indicated on the name plate of the chiller (voltage, frequency, air pressure, air temperature, ambient temperature etc.).

Prior to delivery, this chiller was thoroughly tested, packed and checked. Please verify the soundness of the chiller during the initial start-up and check the perfect functioning during the first operating hours.



The initial start-up must be carried out by qualified personnel.  
During the installation and operation of this device, all national regulations regarding electronics and any other federal and state ordinances, as well as local provisions, need to be adhered to.

The operator and the user must ensure that the chiller is not operated without panels.



## 9.2 Initial start-up



### Note!

The chiller **must not be started up more than six times an hour**. Wait at least five minutes prior to every restart.

The user is responsible for the compliance with these provisions. Irreparable damage can be caused by starting up the device too often.



The method below should be applied during the first start-up, after longer downtimes or subsequent to maintenance works.

The start-up must be carried out by certified skilled personnel.

### Processing sequence (observe Section 11.1 "Control panel")

- Ensure that all steps of the "Installation" chapter have been carried out.
- Ensure that the connection to the compressed-air system is in accordance with the provisions and that the lines are fixed and supported properly.
- Ensure that the condensate drain pipe is fixed in accordance with the provisions and that it is connected with a collection system or a container.
- Ensure that the bypass system (if available) is open and that the chiller is isolated.
- Ensure that the manual valve of the condensate outlet is open.
- Ensure that the cooling-water flow and the temperature are in accordance with the provisions (water-cooled).
- Remove any packaging material and other items which may block the space around the chiller.
- Switch on the main switch.
- Switch on the main switch on the control panel (pos. 1).
- The display of the DMC24 shows **oFF**.
- **When the alarm LED flashes  and the display of the DMC24 shows **oFF** and **Con**, the current phases are not connected correctly. Change two of the three phases at the supply mains (see Section 8.7).**
- Wait at least two hours before starting the chiller (the crankcase heater of the compressor needs to heat up the compressor oil).
- Press the  button for at least two seconds to start the chiller: If the compressor was out of operation for a sufficient period of time, it will start immediately. If this is not the case, the display shows the countdown of the seconds until the compressor restarts and the  LED flashes (max. delay five minutes).
- Make sure that the consumption complies with the values of the name plate.
- **Ensure that the direction of rotation of the fan corresponds to the arrows on the condenser (air-cooled).**
- Wait until the chiller stabilises at the preset value.
- Slowly open the air inlet valve.
- Slowly open the air outlet valve.
- Slowly close the central bypass valve of the system (if installed).
- Check the pipes for air leakage.
- Ensure that the drain discharges at regular intervals – wait for the first interventions.



### CAUTION!

**Please observe the direction of rotation of the compressor!**

**In this system, the direction of rotation of the compressor is supervised by a reverse-phase protector (RPP).**

When this guard is triggered, the alarm will be activated at the DMC24 (the alarm LED flashes  and the display of the DMC24 shows **oFF** and **Con**). In the event that the compressor does not run, the direction of rotation must be changed by interchanging two phases. These modifications must only be carried out by a qualified electrician.

**Do not by-pass the RPP protector: If the device is operated with the incorrect direction of rotation, the compressor will fail immediately. This will void the guarantee.**

### 9.3 Start-up and shut down



During short-term shut down (max. two to three days), it is advisable to leave the chiller and the control panel connected to the supply current circuit. Otherwise, it would be necessary at a restart of the chiller to wait two hours, until the oil in the compressor has reached the specified operating temperature.



#### Start-up (see Section 11.1 "Control panel")

- Make sure that the condenser is clean (air-cooled).
- Ensure that the cooling-water flow and the temperature are in accordance with the provisions (water-cooled).
- Display DMC24 shows **oFF**.
- Press the  button for at least two seconds to start the chiller: If the compressor was out of operation for a sufficient period of time, it will start immediately. If this is not the case, the display shows the countdown of the seconds until the compressor restarts and the  LED flashes (max. delay five minutes).
- Wait for several minutes and then check whether or not the dew point temperature which is indicated on the display of the DMC24 electronics is correct and whether or not the condensate is discharged at regular intervals.
- Switch on the air compressor.



#### Shut down (see Section 11.1 "Control panel")

- Ensure that the dew point temperature indicated on the DMC24 is within the permissible range.
- Shut down the air compressor.
- Switch the chiller off after several minutes by pressing the  button on the DMC24 for at least two seconds. The display then shows **oFF**.



#### Chiller remote control ON/OFF

- See instructions in Section 11.16.7



Only use potential-free contacts that are suitable for low voltage. Ensure the sufficient insulation of potentially dangerous voltage-carrying components.



#### CAUTION!

**Automatic restart / remote control ON/OFF. The unit may start up without any active influence!**

**The user will be responsible for the installation of proper protections for possible sudden power restoration to the chiller.**



#### Note!

A dew point between 0°C and +10°C displayed on the control unit is considered to be correct according to the possible operating conditions (flow rate, air inlet temperature, ambient temperature etc.).

During the operation, the refrigerating compressor runs continuously. The chiller needs to be switched on during the entire compressed-air usage time, even if the compressed-air compressor works periodically.



#### Note!

The chiller **must not be started up more than six times an hour**. Wait at least five minutes prior to every restart.

The user is responsible for the compliance with these provisions. Irreparable damage can be caused when starting up the device too often.

## 10 Technical data

### 10.1 Technical data BEKOBLIZZ LC 480-720 3/400/50

MODEL	BEKOBLIZZ LC	480	600	720
Air flow rate at nominal condition (1)	[m <sup>3</sup> /h]	480	600	720
	[l/min]	8000	10000	12000
	[scfm]	283	353	424
Pressure DewPoint at nominal condition (1)	[°C]	5		
Cooling capacity	[kW]	8.10	10.40	11.80
Nominal ambient temperature	[°C]	25		
Min...Max ambient temperature	[°C]	1...50		
Nominal inlet air temperature (max.)	[°C]	35 (55)		
Outlet air temperature	[°C]	≤ 5		
Nominal inlet air pressure	[barg]	7		
Max. inlet air pressure	[barg]	15		
Air pressure drop - Δp	[bar]	0.22	0.18	0.21
Inlet - Outlet connections	[BSP-F]	G 2"		

Air-Cooled	Refrigerant type	R407C			
	Refrigerant quantity (2)	[kg]	2.90	3.90	4.40
	Cooling air fan flow	[m <sup>3</sup> /h]	7200		7400
	Heat Rejection	[kW]	10.10	12.95	17.15
	Standard Power Supply (2)	[Ph/V/Hz]	3/400/50		
	Nominal electric consumption	[kW]	2.85	3.10	3.50
		[A]	5.0	5.5	6.2
	Full Load Amperage FLA	[A]	8.7	10.2	11.2
	Max. noise level at 1 m	[dbA]	< 75		
	Weight	[kg]	218	235	245

Water-Cooled	Refrigerant type	R407C			
	Refrigerant quantity (2)	[kg]	2.80	3.10	3.70
	Max. cooling water inlet temp (3)	[°C]	30		
	Min...Max. cooling water inlet pressure	[barg]	3...10		
	Cooling water flow at 15°C	[m <sup>3</sup> /h]	0.24	0.32	0.36
	Cooling water flow at 30°C	[m <sup>3</sup> /h]	0.79	1.11	1.19
	Heat Rejection	[kW]	10.10	12.95	17.15
	Control of cooling water flow		Automatic by valve		
	Cooling water connection	[BSP-F]	G 3/4"		
	Standard Power Supply (2)	[Ph/V/Hz]	3/400/50		
	Nominal electric consumption	[kW]	2.40	2.65	3.00
		[A]	4.0	4.5	5.2
	Full Load Amperage FLA	[A]	7.0	8.5	9.5
Max. noise level at 1 m	[dbA]	< 70			
Weight	[kg]	213	230	240	

(1) The nominal condition refers to an ambient temperature of +25°C with inlet air at 7 barg and +35 °C.

(2) Check the data shown on the identification plate.

(3) Other temperature on request.

10.2 Technical data BEKOBLIZZ LC 480-720 3/460/60

MODEL	BEKOBLIZZ LC	480-R	600-R	720-R
Air flow rate at nominal condition (1)	[m <sup>3</sup> /h]	480	600	720
	[l/min]	8000	10000	12000
	[scfm]	283	353	424
Pressure DewPoint at nominal condition (1)	[°C]	5		
Cooling capacity	[kW]	9.50	11.50	13.70
Nominal ambient temperature	[°C]	25		
Min...Max ambient temperature	[°C]	1...50		
Nominal inlet air temperature (max.)	[°C]	35 (55)		
Outlet air temperature	[°C]	≤ 5		
Nominal inlet air pressure	[barg]	7		
Max. inlet air pressure	[barg]	15		
Air pressure drop - Δp	[bar]	0.22	0.18	0.21
Inlet - Outlet connections	[BSP-F]	G 2"		

Air-Cooled	Refrigerant type	R407C			
	Refrigerant quantity (2)	[kg]	2.90	3.70	3.90
	Cooling air fan flow	[m <sup>3</sup> /h]	7900		8200
	Heat Rejection	[kW]	11.90	15.30	19.37
	Standard Power Supply (2)	[Ph/V/Hz]	3/460/60		
	Nominal electric consumption	[kW]	3.30	3.80	4.25
		[A]	5.1	5.9	6.4
	Full Load Amperage FLA	[A]	9.0	10.5	11.5
	Max. noise level at 1 m	[dbA]	< 75		
	Weight	[kg]	218	235	245

Water-Cooled	Refrigerant type	R407C			
	Refrigerant quantity (2)	[kg]	2.30	2.80	3.10
	Max. cooling water inlet temp (3)	[°C]	30		
	Min...Max. cooling water inlet pressure	[barg]	3...10		
	Cooling water flow at 15°C	[m <sup>3</sup> /h]	0.29	0.39	0.44
	Cooling water flow at 30°C	[m <sup>3</sup> /h]	1.10	1.46	1.47
	Heat Rejection	[kW]	11.90	15.30	19.37
	Control of cooling water flow	Automatic by valve			
	Cooling water connection	[BSP-F]	G 3/4"		
	Standard Power Supply (2)	[Ph/V/Hz]	3/460/60		
	Nominal electric consumption	[kW]	2.80	3.10	3.50
		[A]	4.1	4.7	5.2
	Full Load Amperage FLA	[A]	7.0	8.5	9.5
	Max. noise level at 1 m	[dbA]	< 70		
Weight	[kg]	213	230	240	

(1) The nominal condition refers to an ambient temperature of +25°C with inlet air at 7 barg and +35 °C.


(2) Check the data shown on the identification plate.

(3) Other temperature on request.

## 11 Technical description

### 11.1 Control panel

The control panel explained below is the only chiller user interface.




- 1 Main switch
- 2 Electronic control unit DMC 24
- 3 Air and refrigerant-gas flow chart

### 11.2 Functional description


**Operating principle** – All chiller models described in this manual function according to the same principle. The hot and moisture-loaded air flows through an evaporator, which is also known as an air/refrigerant heat exchanger. The air temperature is reduced to approximately 5°C, so that water vapour condenses to liquid. The continuously accumulating condensate is collected in the separator to be discharged via the condensate drain.

**Refrigeration cycle** – The refrigerant is conducted through the compressor and reaches a condenser under high pressure. There, cooling-down takes place, making the refrigerant condense to a liquid state which is under high pressure. The liquid is pressed through a capillary tube where the resulting pressure drop ensures that the refrigerant evaporates at a defined temperature. The liquid refrigerant which is under low pressure is led into the heat exchanger, where it expands. The cold resulting from the expansion serves to cool down the compressed air in the heat exchanger. During this process, the refrigerant evaporates. The low-pressure gas is resupplied to the compressor, where it is compressed again. It then re-enters the cycle. In phases of a reduced compressed-air load, the excess refrigerant is resupplied automatically to the compressor via the hot gas bypass valve.

11.3 Flow chart (air-cooled)



11.4 Flow chart (water-cooled)



- |  |  |
|--|--|
| 1 Heat exchanger group                 | 12.2 T2 Temperature probe – Air IN               |
| a – Air/air heat exchanger             | 12.3 T3 Temperature probe – Compressor suction   |
| b – Condensate separator               | 12.4 T4 Temperature probe – Compressor discharge |
| 2 Refrigerant pressure switch LPS (P<) | 13 Condensate drain isolation valve              |
| 4 Refrigerant pressure switch HPS (P>) | 18 Condenser (water-cooled)                      |
| 6 Refrigerating compressor             | 19 Cooling-water regulating valve (water-cooled) |
| 7 Hot-gas bypass valve                 | 20 Liquid collector (water-cooled)               |
| 8 Condenser (air-cooled)               | 21 BEKOMAT condensate drain                      |
| 9 Condenser fan (air-cooled)           | 25 Compressor crankcase heater RC                |
| 10 Filter dryer                        | 36 Liquid separator                              |
| 11 Capillary tube                      | 37 Sensor for the fan control (BHP)              |
| 12.1 T1 Temperature probe – Dew point  |  |
| ➡ Compressed-air flow direction        | ➡ Refrigerant gas flow direction                 |

### 11.5 Refrigerating compressor

The employed refrigerating compressors are constructed by leading manufacturers. The hermetically sealed construction is absolutely gastight. The integrated safeguard protects the compressor against overheating and excess current. The protection is automatically reset as soon as the nominal conditions are reached again.

### 11.6 Condenser (air-cooled)

The condenser is the component in which the gas coming from the compressor is cooled down, condensed and liquefied. Under no circumstances must the temperature of the ambient air exceed the nominal values. It is also important that the condenser unit is kept free from dust and other impurities.

### 11.7 Condenser (water-cooled)

The condenser is the component in which the gas coming from the compressor is cooled-down, condensed and liquefied.

The water inlet temperature must not exceed the nominal values. Likewise, a correct flow must be ensured. The water entering the condenser must be free from impurities.

### 11.8 Cooling-water regulating valve

The cooling-water controller serves to keep the condensation pressure or the condensation temperature constant during water cooling. When the chiller is switched off, the valve automatically blocks the cooling-water flow.

### 11.9 Filter dryer

Despite controlled vacuuming, traces of moisture can accumulate in the refrigeration cycle. The filter dryer serves to absorb this moisture and to bond it.

### 11.10 Capillary tube

The capillary tube is a copper tube with a reduced diameter which is located between the condenser and the evaporator, serving as a restrictor to reduce the pressure of the refrigerant. The pressure reduction serves to reach an optimum temperature inside of the evaporator. The lower the outlet pressure at the capillary tube, the lower the evaporation temperature.

The length and the inner diameter of the capillary tube are exactly dimensioned to ensure the performance of the chiller. Settings or maintenance works are not required.

### 11.11 Air-to-refrigerant heat exchanger

Also called evaporator. The liquid formed in the condenser is evaporated in this part of the circuit. In the evaporation phase the refrigerant tends to absorb the heat from the compressed air present in the other side of the exchanger.

Refrigerant and air are in counter flow, thus contributing to limit pressure drop and to provide efficient thermal exchange.

### 11.12 Condensate separator

The cold air exiting the evaporator goes through the hi-efficiency condensate separator featuring a stainless steel mesh. As the condensate transported by the air gets in contact with the mesh net it is separated and expelled by means of the draining device. The resulting cold and dry air is then conveyed into chiller outlet.

The mesh type mist separator offers the benefit to be highly efficient even with variable flow rates.

### 11.13 Hot-gas bypass valve

At partial load, the valve directly returns a part of the hot gas to the suction line of the refrigerating compressor. The evaporation temperature and the evaporation pressure remain constant.

### 11.14 Refrigerant pressure switches LPS – HPS

To ensure the operational reliability and the protection of the chiller, a series of pressure switches are installed in the gas cycle.

**LPS :** Low-pressure appliance on the suction side of the compressor, which is triggered when the pressure drops below the predetermined value. The values are reset automatically as soon as the nominal conditions are re-established.

**HPS :** The high-pressure appliance on the discharge side of the compressor is activated when the pressure exceeds the predetermined value. The values are not reset automatically when the nominal conditions are re-established. Reset takes place manually via a button on the appliance.

### 11.15 Compressor crankcase heater

During a longer downtime, the oil can intermix with the refrigerant. Therefore, "hydraulic shocks" may occur during the start-up of the compressor.


To prevent this, a heating resistor was installed in the housing of the compressor which maintains a corresponding oil temperature when the control panel is switched on and the compressor is idle.



**Note!**

The heating resistor needs to be switched on at least two hours prior to the start-up of the refrigerant compressor.

11.16 DMC 24 electronics (control unit compressed-air chiller)



LED	
	Compressor ON - green
	Drain ON – green
	Fan 1 <sup>st</sup> stage ON – green
	Fan 2 <sup>nd</sup> stage ON – green
	Service warning – orange
	Alarm – red
<i>remote</i>	Remote control active
	Temperature in °C
	Temperature in °F
	Pressure in bar(g)
	Pressure in psi(g)

BUTTON	
	ON
	OFF
	Increase
	Decrease
	Log
	Info menu
	Test button condensate drain / ESC
	Instrument setting menu
	Reset alarm and/or service

The DMC24 controls all operations, alarms and instrument settings of the chiller. The display and the LEDs indicate all operating conditions.

The LED shows that the compressor is ON.

Operation of the fans is indicated by the and LEDs.

During normal operation, the display shows the dew point temperature.

11.16.1 Switching the chiller on

When the unit is switched on, the display shows **OFF**.

The condensate drain test is always possible via the button.

- Press the button for at least two seconds to start the chiller: If the compressor was out of operation for a sufficient period of time, it will start immediately. If this is not the case, the display shows the countdown of the seconds until the compressor restarts and the LED flashes (max. delay five minutes).

11.16.2 Switching the chiller off

Press for at least two seconds from any menu. The display shows **OFF**.

**11.16.3 Indication of the operating parameters – Info menu**

The Info menu shows the dynamic operating parameters of the chiller.

When the chiller is ON and you are not in other menus, press  for at least one second to access the Info menu.

Access to the Info menu is indicated on the display by the message **t 1** (first parameter of the menu). Use the  and  arrows to move to the next or previous point. Press  to have the value of the selected parameter displayed. Press  again to return to the list of displayable parameters.

Press  to leave the Info menu (if, after a period of two minutes, no button is pressed, the menu is exited automatically).

Info	Description
<b>t 1</b>	T1 – Temperature probe T1 – dew point
<b>t 2</b>	T2 – Temperature probe T2 – Air IN
<b>t 3</b>	T3 – Temperature probe T3 – Compressor suction
<b>t 4</b>	T4 – Temperature probe T4 – Compressor discharge
<b>HP</b>	HP – Condensation pressure HP
<b>HrS</b>	HrS – Total number of operating hours
<b>SrV</b>	SrV – Hours to the next maintenance

**Note:** The temperatures are indicated in °C or °F (LED  °C or  °F is on).

The pressure is indicated in bar(g) or psi(g)(LED  bar or  psi is on).

The total operating hours and the hours until the next maintenance are indicated in the field 0...999 hours, and in thousand hours from 1.0 hours onwards (example: when the display shows 35, this means 35 hours and when the display shows 3.5, this means 3,500 hours).

### 11.16.4 Indication of a service warning

A service warning is an exceptional event and requires the attention of the operator/service technician. Such a warning will usually not stop the chiller (unless a high dew point parameter was adjusted to stop the chiller).

When a service warning is active, the  LED flashes. When the service warning was automatically reset, it has been stored and the  LED is continuously on.

In both cases the display shows the dew point temperature and the service warnings which are active or which are no longer active but not yet reset.

Service warnings are not automatically reset (except for *drn* which can be put on automatic reset).

To **RESET** the service warning, simultaneously press the   buttons for three seconds. Only the stored service warning will be reset. Service warnings which are still active continue to be indicated by the flashing  LED.

**NOTE: the operator/service technician must check the chiller and eliminate the problem that led to the activation of the service warning.**

Service warning	Description
<i>PF 1</i>	PF1 – Probe 1 failure: failure temperature probe 1
<i>PF 2</i>	PF2 - Probe 2 failure: failure temperature probe 2
<i>PF 3</i>	PF3 - Probe 3 failure: failure temperature probe 3
<i>HdP</i>	HdP – High dew point: dew point too high, higher than the adjusted HdA value.
<i>LdP</i>	LdP – Low dew point: dew point too low Setting T1< -1°C (30°F) delay five minutes / reset T1> 0°C (32°F)
<i>drn</i>	drn - Drain: failure condensate drain (opening of the DRN contact – if an electronically level-controlled condensate drain is installed – see electric diagram)
<i>SrV</i>	SrV - Service : maintenance service time expired SrV
<i>dt</i>	dt – Outlet temperature: compressor outlet temperature (probe T4) outside the normal values but within the safety limits Setting T4> 90°C (194°F) delay three minutes / reset T4< 85°C (185°F)
<i>HCP</i>	HCP – High condensation pressure: condensation pressure (transformer HP) outside the normal values but within the safety limits Setting HP> 28barg (406psig) delay three minutes / reset HP< 25barg (363psig)

**NOTE: when the chiller is switched on but no system pressure is applied, the *drn* drain trouble indication may appear.**

## Technical description

### 11.16.5 Alarm indication

An alarm is an exceptional event which, to avert damage from to the machine and the operator, always leads to the disconnection of the chiller.

When the alarm is active, the  LED flashes. When the alarm was not automatically reset, it is stored and the  LED is on (in any case, the chiller remains OFF).

When the  LED flashes, the **OFF** message and the active alarms will appear in sequence on the display.

When the  LED is on, the **OFF** message and the alarms which triggered and which need to be reset will appear in sequence on the display.

The alarms are not automatically reset. To **RESET** an alarm, the  LED needs to be on and the   buttons must be pressed simultaneously for at least three seconds.

The chiller will not start automatically subsequent to the reset of the alarms.

**NOTE: the operator/service technician must check the chiller and eliminate the problem that led to the activation of the alarm.**

Alarm	Description
<b>HP</b>	HP – High pressure: the refrigerant high-pressure guard HPS has triggered (note: the pressure switch has a reset button)
<b>LP</b>	LP – Low pressure: the refrigerant low-pressure guard LPS has triggered
<b>CO<sub>n</sub></b>	CO <sub>n</sub> - Compressor: the compressor protection and/or the reverse-phase protector RPP have triggered
<b>FA<sub>n</sub></b>	FA <sub>n</sub> - Fan: the fan protection has triggered
<b>Hdt</b>	Hdt – High outlet temperature: compressor outlet temperature outside the safety limit Setting T4 > 100°C (212°F) delay one minute / reset T4 < 90°C (194°F)
<b>ICE</b>	ICE - ICE / Icing: Temperature in the exchanger (probe T1) is too low and leads to icing of the condensate. Setting T1 < -3°C (27°F) delay one minute / reset T1 > 0°C (32°F)
<b>LCP</b>	LCP – Low condensation pressure: condensation pressure too low
<b>PF4</b>	PF4 – Probe 4 failure: failure probe 4
<b>PFP</b>	PFP – Probe pressure failure: failure condensation pressure transducer BHP

### 11.16.6 Display of the alarm memory – log menu

The log menu includes a list of the last 10 alarms (only alarms, no service warnings). They appear in chronological order (LIFO logic).

When the chiller is ON or OFF, and when you are not in another menu, press the  button for at least one second to access the log menu.

The access to the log menu is confirmed on the display by the message **L01** (L01) (first parameter of the menu). Use the  and  arrows to move to the next or previous point (L01 ... L10). Press  to have the selected log value displayed. Alternatively, the parameter that triggered the alarm and the operating hours of the machine at the moment of the alarm activation are indicated. Press  again to return to the log list.

Press  to leave the log menu (if, after a period of two minutes, no button is pressed, the menu is exited automatically).

### 11.16.7 Control of the chiller via remote control

The DMC24 can easily be controlled via two digital inputs which are connected with terminals 1, 2 and 3 (see electric diagram).

Close the contact between terminals 2 and 3 to enable the remote control. The *remote*  LED lights up and it is no longer possible to switch the chiller on or off from the local control panel (the condensate drain test is possible and you have access to the info and log menus).

When the contact between terminals 2 and 3 is closed, close the second contact between terminals 1 and 2 to switch on the chiller. Open the contact between terminals 1 and 2 to switch off the chiller.



Only use potential-free contacts that are suitable for low voltage. Ensure the sufficient insulation of potentially dangerous voltage-carrying components.




#### CAUTION!


**Automatic restart / remote control ON/OFF. The unit may start up without any active influence!**  
**The user will be responsible for the installation of proper protections for possible sudden power restoration to the chiller.**

### 11.16.8 Operation of the potential-free failure/alarm contact

The DMC24 is equipped with a potential-free contact to indicate failures or alarm conditions.



Chiller is switched on, no service warning and no alarm (active and not yet reset) indicated.



Chiller is off or a service warning or alarm (active and not yet reset) is indicated.

### 11.16.9 Connection to a serial line

The DMC24 can be connected to a serial monitoring line, a remote control or a notebook for the download of the alarm log files (memory).

For further information, please contact your retailer or your service centre.

## Technical description

### 11.16.10 Operating parameters – setup menu

The setup menu can be used to change the chiller's operating parameters.



Only qualified personnel must be allowed to access to the setup menu. The manufacturer is not responsible for malfunctioning or failure due to modification to the operating parameters.

With chiller ON or OFF and not in other menus, simultaneously press buttons   for at least 5 seconds to enter the setup menu.

Access to the info menu is confirmed by message **ton** on the display (first parameter of menu). Use arrows  and  to move to following/previous one.

Keep  pressed to display the value of the selected parameter and use arrows  and  to change the value. Release the button  to confirm the value and skip to following parameter.

Press  to exit setup menu (if no button is pressed after 2 minutes the menu is exited automatically).

ID	Description	Limits	Resolution	Standard setup
<b>ton</b>	Ton – drain time ON : time ON condensate drain valve <b>00 = Electronic drainer installed</b>	00 ... 20 sec	1 sec	00
<b>toF</b>	ToF - drain time OFF : pause time for condensate drain valve	1 ... 20 min	1 min	1
<b>HdA</b>	HdA - High DewPoint Alarm : Alarm threshold for a high DewPoint (the alarm disappears when the temperature drop 1°C / 2°F below alarm point)	0.0...25.0 °C or 32 ... 77 °F	0.5 °C or 1 °F	20 or 68
<b>Hdd</b>	Hdd - High DewPoint Delay : high DewPoint alarm enable delay	01 ... 20 minutes	1 min	15
<b>HdS</b>	HdS - High DewPoint alarm STOP : select if high DewPoint alarm stops chiller (YES) or does not stop chiller (nO)	YES ... nO	-	nO
<b>SrV</b>	SrV - Service Setting: setting of service warning timer. 00 = service warning timer disabled.	0.0 ... 9.0 (x 1000) hours	0.5 (x1000) hours	8.0
<b>SCL</b>	SCL - Scale: display scale of temperatures and pressure. (Note : setting °C = temperature in °C and pressure in bar; setting °F = temperature in °F and pressure in psi)	°C ... °F	-	°C
<b>AS</b>	AS - Auto Restart : automatic re-start at power supply. YES = at power supply chiller starts up again automatically (if it was ON) nO = at power supply chiller is always OFF	YES ... nO	-	nO
<b>Ard</b>	Ard - Auto Reset service drain : automatic reset of service drain YES = automatic reset at normal conditions nO = manual reset required	YES ... nO	-	YES
<b>IPA</b>	IPA - IP Address : selection of IP address to use in serial connection line	1 ... 255	1	1



**AS = YES - CAUTION -**

**THE CHILLER MAY POWER UP WITHOUT BEING ACTED UPON.**

**THE USER WILL BE RESPONSIBLE FOR THE INSTALLATION OF PROPER PROTECTIONS FOR POSSIBLE SUDDEN POWER RESTORATION TO THE CHILLER.**

### 11.17 Electronically level-controlled BEKOMAT condensate drain

The electronically level-controlled BEKOMAT condensate drain boasts a special condensate management which ensures that condensate is discharged safely and without an unnecessary loss of compressed air. This drain has a condensate collection container in which a capacitive sensor continuously monitors the liquid level. As soon as the switching level is reached, the capacitive sensor transmits a signal to the electronic control and a membrane solenoid valve opens to discharge the condensate. The BEKOMAT closes before compressed air emerges.

**Note!**

These BEKOMAT condensate drains were designed in particular for the operation in a **BEKOBLIZZ LC** refrigeration chiller. The installation in other compressed-air processing systems or the replacement with another drain brand can lead to malfunction. The maximum operating pressure (see name plate) must not be exceeded!

**Ensure that the upstream valve is open when the chiller starts operation.**

**To obtain detailed information regarding drain functions, troubleshooting, maintenance and spare parts, please read the installation and operating instructions of the BEKOMAT condensate drain.**

## 12 Maintenance, troubleshooting, spare parts and dismantling

### 12.1 Checks and maintenance



#### Certified skilled personnel

Installation works must exclusively be carried out by authorised and qualified skilled personnel. Prior to undertaking any measures on the BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller, the certified skilled personnel<sup>4</sup> shall read up on the device by carefully studying the operating instructions. The operator is responsible for the adherence to these provisions. The respective directives in force apply to the qualification and expertise of the certified skilled personnel.

For safe operation, the device must only be installed and operated in accordance with the indications in the operating instructions. In addition, the national and operational statutory provisions and safety regulations, as well as the accident prevention regulations required for the respective case of application, need to be observed during employment. This applies accordingly when accessories are used



#### Danger!

##### Compressed air!

**Risk of serious injury or death through contact with quickly or suddenly escaping compressed air or through bursting and/or unsecured plant components.**

Compressed air is a highly dangerous energy source.

Never work on the chiller when the system is under pressure.

Never direct the compressed-air outlet or condensate drain hoses at persons.

The user is responsible for the proper maintenance of the chiller. Non-observance of the instructions in the "Installation" and "Maintenance, troubleshooting, spare parts and dismantling" chapters leads to the expiration of the guarantee. Improper maintenance may result in dangerous situations for the personnel and/or the device.



#### Danger!

##### Supply voltage!

**Contact with non-insulated parts carrying supply voltage involves the risk of an electric shock resulting in injuries and death.**

Only qualified and skilled personnel are authorised to run electrically-operated devices. Prior to undertaking maintenance measures at the device, the following requirements must be met:

Make sure that the power supply is switched off and that the device is off and marked for maintenance measures. Please also ensure that the power supply cannot be re-established during the works.



Prior to carrying out maintenance works at the chiller, switch it off and wait for at least 30 minutes.



#### Caution!

##### Hot surfaces!

**During operation, several components can reach surface temperatures of more than +60°C. There is the risk of burns.**

All components concerned are installed inside of the closed housing. The housing must only be opened by certified skilled personnel.

Some components can reach high temperatures during operation. Avoid any contact until the system or the component has cooled down.

---

<sup>4</sup> Certified skilled personnel are persons who are authorised by the manufacturer, with experience and technical training, who are well-grounded in the respective provisions and laws and capable of carrying out the required works and of identifying and avoiding any risks during the machine transport, installation, operation and maintenance. Qualified and authorised operators are persons who are instructed by the manufacturer regarding the handling of the refrigeration system, with experience and technical training, and who are well-grounded in the respective provisions and laws.

**DAILY:**

- Check whether the dew point indicated on the electronics is correct.
- Ensure that the condensate drain system functions properly.
- Make sure that the condenser is clean.

**EVERY 200 HOURS OR MONTHLY**

- Clean the condenser using an air jet (max. 2 bar / 30 psig) inside out. Make sure not to damage the aluminium lamellae of the cooling package.
- Finally, verify the operation of the device.

**EVERY 1,000 HOURS OR ANNUALLY**

- Verify all screws, clamps and connections of the electric system to make sure that they are fastened securely. Check the device for broken and ruptured cables or cables without insulation.
- Check the refrigeration cycle for signs of oil and refrigerant leaks.
- Measure the current strength and note it down. Ensure that the read values are within the permissible limit values, as indicated in the specification table.
- Check the hose lines of the condensate drain and replace them, if required.
- Finally, verify the operation of the device.

**EVERY 8,000 HOURS**

- Replace BEKOMAT Service Unit.

**12.2 Troubleshooting****Certified skilled personnel**

Installation works must exclusively be carried out by authorised and qualified skilled personnel. Prior to undertaking any measures on the BEKOBLIZZ® LC 480-720 compressed-air refrigeration chiller, the certified skilled personnel shall read up on the device by carefully studying the operating instructions. The operator is responsible for the adherence to these provisions. The respective directives in force apply to the qualification and expertise of the certified skilled personnel.

For safe operation, the device must only be installed and operated in accordance with the indications in the operating instructions. In addition, the national and operational statutory provisions and safety regulations, as well as the accident prevention regulations required for the respective case of application, need to be observed during employment. This applies accordingly when accessories are used.

**Danger!****Compressed air!**

**Risk of serious injury or death through contact with quickly or suddenly escaping compressed air or through bursting and/or unsecured plant components.**

Compressed air is a highly dangerous energy source.

Never work on the chiller when the system is under pressure.

Never direct the compressed-air outlet or condensate drain hoses at persons.

The user is responsible for the proper maintenance of the chiller. Non-observance of the instructions in the "Installation" and "Maintenance, troubleshooting, spare parts and dismantling" chapters leads to the expiration of the guarantee. Improper maintenance may result in dangerous situations for the personnel and/or the device.

**Danger!****Supply voltage!**

Contact with non-insulated parts carrying supply voltage involves the risk of an electric shock resulting in injuries and death.

Only qualified and skilled personnel are authorised to run electrically-operated devices. Prior to undertaking maintenance measures at the device, the following requirements must be met:

Make sure that the power supply is switched off and that the device is off and marked for maintenance measures. Please also ensure that the power supply cannot be re-established during the works.



Prior to carrying out maintenance works at the chiller, switch it off and wait for at least 30 minutes.



**Caution!**  
**Hot surfaces!**

During operation, several components can reach surface temperatures of more than +60°C. There is the risk of burns.

All components concerned are installed inside of the closed housing. The housing must only be opened by certified skilled personnel.

Some components can reach high temperatures during operation. Avoid any contact until the system or the component has cooled down.

FAULT	POSSIBLE REASON – SUGGESTED MEASURE
◆ The chiller does not start.	<ul style="list-style-type: none"> <li>⇒ Check the power supply.</li> <li>⇒ Check the electric cabling.</li> <li>⇒ Fuse breakdown (see FU1/FU2/FU4 in the electric diagram) in the auxiliary circuit – replace it and check the proper operation of the chiller.</li> <li>⇒ <b>DMC24-</b> The  LED is on – see the corresponding point.</li> </ul>
◆ The refrigerating compressor does not work.	<ul style="list-style-type: none"> <li>⇒ The internal guard was activated – wait 30 minutes and then recheck.</li> <li>⇒ Check the electric cabling.</li> <li>⇒ <b>DMC24-</b> Internal delay of the device – the display shows the seconds prior to the start-up.</li> <li>⇒ <b>DMC24-</b> The  LED is on – see the corresponding point.</li> <li>⇒ In the event that the compressor still does not work, replace it.</li> </ul>
◆ The fan of the condenser does not work (air-cooled).	<ul style="list-style-type: none"> <li>⇒ Check the electric cabling.</li> <li>⇒ Power contactor of the fan is defective (see KV1/KV2 in the electric diagram) – replace it.</li> <li>⇒ <b>DMC24-</b> The  LED is on – see the corresponding point.</li> <li>⇒ Refrigerant gas loss – contact a specialist for refrigerating plants.</li> <li>⇒ In the event that the fan still does not work, replace it.</li> </ul>
◆ Dew point too high	<ul style="list-style-type: none"> <li>⇒ Chiller does not start up – see the corresponding paragraph.</li> <li>⇒ The T1 dew point sensor does not record the temperature properly – ensure that the sensor is pushed down to the bottom of the aluminium tube immersion sleeve.</li> <li>⇒ The refrigerating compressor does not work – see the corresponding paragraph.</li> <li>⇒ The room temperature is too high or the air change insufficient – ensure sufficient ventilation (air-cooled).</li> <li>⇒ The inlet air is too hot – re-establish the operating conditions indic.on the name plate.</li> <li>⇒ The inlet air pressure is too low - re-establish the operating conditions indic.on the name plate.</li> <li>⇒ The inlet air throughput is higher than the throughput intended for operation – reduce the throughput - re-establish the operating conditions indic.on the name plate.</li> <li>⇒ The condenser is dirty – please clean it (air-cooled).</li> <li>⇒ The fan does not work – see the corresponding paragraph (air-cooling).</li> <li>⇒ The cooling water is too hot - re-establish the operating conditions indic.on the name plate (water-cooled).</li> <li>⇒ The cooling-water flow is insufficient - re-establish the operating conditions indic.on the name plate (water-cooled).</li> <li>⇒ The chiller does not discharge condensate – see the corresponding paragraph.</li> <li>⇒ The hot-gas bypass valve needs to be re-adjusted – contact a specialist for refrigerating plants to have the nominal calibration re-established.</li> <li>⇒ Refrigerant gas loss – contact a specialist for refrigerating plants.</li> </ul>

◆ Dew point too low.	<ul style="list-style-type: none"> <li>⇒ The fan runs continuously – ensure perfect functioning of the fan power contactor (see KV1/KV2 on the electric diagram) and/or of the pressure transducer (see BHP on the electric diagram) – (air-cooled).</li> <li>⇒ The ambient temperature is too low – re-establish the conditions indic.on the name plate.</li> <li>⇒ The hot-gas bypass valve needs to be re-adjusted – contact a specialist for refrigerating plants to have the nominal calibration re-established.</li> </ul>
◆ Extreme pressure drop in the chiller.	<ul style="list-style-type: none"> <li>⇒ The chiller does not discharge the condensate – see the corresponding paragraph.</li> <li>⇒ The pressure dew point is too low – the condensate is frozen, therefore, air cannot enter – see the corresponding paragraph.</li> <li>⇒ Make sure that the connection hoses are not pinched off.</li> </ul>
◆ The chiller does not drain the condensate.	<ul style="list-style-type: none"> <li>⇒ The system pressure is too low and condensate is not discharged – re-establish the nominal conditions.</li> <li>⇒ Valve for the condensate drainage is closed – open the valve.</li> <li>⇒ Check the electric cabling.</li> <li>⇒ Pressure dew point too low – the condensate is frozen – see the corresponding paragraph.</li> <li>⇒ BEKOMAT-discharge unit does not work properly (see BEKOMAT manual).</li> </ul>
◆ The chiller continuously discharges condensate.	<ul style="list-style-type: none"> <li>⇒ BEKOMAT discharge unit is dirty (see BEKOMAT manual).</li> </ul>
◆ Water in the line.	<ul style="list-style-type: none"> <li>⇒ The chiller does not start – see the corresponding section.</li> <li>⇒ If installed: untreated air flows through the bypass group - close it.</li> <li>⇒ The chiller does not drain condensate – see the corresponding paragraph.</li> <li>⇒ The pressure dew point is too high – see the corresponding paragraph.</li> </ul>
◆ The high-pressure switch HPS has triggered.	<ul style="list-style-type: none"> <li>⇒ Check which of the following reasons is responsible for the triggering:               <ol style="list-style-type: none"> <li>1. The room temperature is too high or the air change insufficient – ensure sufficient ventilation (air-cooled).</li> <li>2. The condenser is dirty – please clean it (air-cooled).</li> <li>3. The fan does not work – see the corresponding paragraph (air-cooled).</li> <li>4. The cooling water is too hot – re-establish the operating conditions indic. on the name plate (water-cooled).</li> <li>5. Cooling-water flow insufficient - re-establish the operating conditions indic. on the name plate (water-cooled).</li> </ol> </li> <li>⇒ Re-adjust the high-pressure switch, press the corresponding push button - check the chiller for proper operation/function.</li> <li>⇒ The HPS pressure failed or is defective – contact a specialist for refrigerating plants – replace the high-pressure switch.</li> </ul>
◆ The LPS low-pressure switch was triggered.	<ul style="list-style-type: none"> <li>⇒ Refrigerant gas loss – contact a specialist for refrigerating plants.</li> <li>⇒ The low-pressure switch is automatically reset as soon as the nominal conditions are re-established – check the chiller for proper functioning.</li> </ul>

- ◆ DMC24-  LED is on.
- ⇒ At a flashing  LED: one or more alarms are active and the display shows **oFF** and the active alarms. When the  LED is lit: one or more alarms need to be reset and the display shows **oFF** and the alarms which are no longer active but which still need to be reset.
- ⇒ The alarms are indicated by the following messages:
1. **HP** : HPS pressure switch triggered (refrigerant high pressure) because the condensation pressure is too high – see the corresponding paragraph (NOTE: press the reset button on the HPS pressure switch when the problem is eliminated).
  2. **LP** : LPS pressure switch triggered (low pressure) because the refrigerant pressure is too low – see the corresponding paragraph.
  3. **Con** : Con – The electrical protection of the compressor has triggered (see Q1/QC1 on the electric diagram) – reset and check the perfect functioning of the chiller.
  4. **Con** : Con – during first startup - The main electrical connection of the compressor are connected incorrectly (see RPP on the electric diagram) – change the direction of rotation and interchange two phases. These modifications must only be carried out by a qualified electrician. DO NOT AVOID THE RPP PROTECTION: If the device is operated with the incorrect direction of rotation, the compressor will fail immediately. This will void the guarantee.
  5. **Con** : Con – one phase of power supply of chiller is missing (see RPP on the electric diagram) – restore the missing phase.
  6. **Con** : Con – Reverse Phase Protector (RPP) is faulty – replace it.
  7. **Con** : Con – If installed – Thermal protection inside the compressor tripped (see MC1 on wiring diagram) – wait 30 minutes and try again.
  8. **FAn** : FAn – The electrical protection of the fan has triggered (see QV1 on the electric diagram) – reset and check the perfect functioning of the chiller (air-cooled).
  9. **FAn** : FAn – The thermal protection in the fan has triggered (see MF on the circuit diagram – wait 30 minutes and retry (air-cooled).
  10. **Hdt** : Hdt – The outlet temperature protection of the compressor has triggered as a result of a very high temperature (probe T4) – see the corresponding paragraph.
  11. **ICE** : ICE – The temperature inside the exchanger (probe T1) is too low – the dew point is too low – see the corresponding paragraph.
  12. **LCP** : LCP – The condensation pressure is too low – see the corresponding paragraph.
  13. **PF4** : PF4 – Failure temperature probe T4 (compressor outlet) – check the electric cabling and/or replace the probe.
  14. **PF4** : PF4 – Failure pressure transducer BHP (condensation pressure) – check the electric cabling and/or replace the transformer.
- NOTE: The alarms need to be reset when the problem is eliminated (simultaneously press the   buttons for three seconds).

- ◆ The DMC24-  LED is on.
- ⇒ When the  LED flashes, one or more service warnings are active. When the  LED is lit: one or more service warnings need to be reset. The display shows the dew point temperature and the service warning which is active or which is not yet reset.
- ⇒ The service warnings are indicated by the following messages:
1. **PF1** : PF1 – Failure temperature probe T1 (dew point) – check the electric cabling and/or replace the probe.
  2. **PF2** : PF2 – Failure temperature probe T2 (air IN) – check the electric cabling and/or replace the probe.
  3. **PF3** : PF3 – Failure temperature probe T3 (compressor intake) – check the electric cabling and/or replace the probe.
  4. **Hdp** : Hdp – Dew point too high (higher than the adjusted alarm value) – see the corresponding paragraph.
  5. **Ldp** : Ldp – Dew point too low – see the corresponding paragraph.
  6. **drn** : drn – The condensate drain does not work properly (condensate drain contact open – if an electronic drain is installed) – see the corresponding paragraph.
  7. **SrV** : SrV - Service – maintenance notification time expired (parameter SrV) – carry out the scheduled maintenance and reset the hour meter.
  8. **dt** : dt – Compressor supply temperature too high (probe T4) – see the corresponding paragraph.
  9. **HCP** : HCP – Condensation pressure too high – see the corresponding paragraph.
- NOTE: The services need to be reset when the problem is eliminated (simultaneously press the   buttons for at least three seconds).

- |   |  |
|---|--|
| ◆ Compressor outlet temperature too high. | ⇒ Find out the reason for the fault: <ol style="list-style-type: none"><li>1. Excessive thermal load – re-establish the nominal conditions.</li><li>2. The inlet air is too hot – re-establish the nominal conditions.</li><li>3. The ambient air temperature is too high or the room ventilation insufficient – ensure sufficient ventilation.</li><li>4. The condenser is dirty – please clean it.</li><li>5. The fan does not work – see the corresponding section.</li><li>6. The fan runs continuously – ensure perfect functioning of the power contactor of the fan (see KV1/KV2 on the electric diagram) and/or of the pressure transducer (see BHP on the electric diagram) – (air-cooled).</li><li>7. The hot-gas bypass valve needs to be re-adjusted – contact a specialist to have the nominal calibration re-established.</li><li>8. The temperature of the cooling water is too low – re-establish the nominal conditions (water-cooled).</li><li>9. The adjusting valve for the cooling-water flow needs to be re-adjusted - contact a specialist to have the nominal calibration re-established (water-cooled).</li><li>10. Refrigerant gas leak – contact a technician for refrigeration plants.</li></ol> |
| ◆ Condensation pressure too high.         | ⇒ Find out the reason for the fault: <ol style="list-style-type: none"><li>1. The ambient air temperature is too high or the air change insufficient in this area – ensure sufficient ventilation (air-cooled).</li><li>2. The condenser filter is dirty – please clean or replace it (air-cooled).</li><li>3. The fan does not work – see the corresponding section (air-cooled).</li><li>4. The cooling water is too hot – re-establish the nominal conditions (water-cooled).</li><li>5. The cooling-water flow is insufficient – re-establish the nominal conditions (water-cooled).</li></ol>   |
| ◆ Condensation pressure too low.          | ⇒ Find out the reason for the fault: <ol style="list-style-type: none"><li>1. The fan runs continuously – ensure perfect functioning of the power contactor of the fan (see KV1/KV2 on the electric diagram) and/or of the pressure transducer (see BHP on the electric diagram).</li><li>2. The ambient temperature is too low – re-establish the nominal conditions.</li><li>3. Air flows through the condenser although the fan is switched off – protect the chiller against wind or external air flows (not caused by the fan of the chiller).</li><li>4. The cooling-water temperature is too low – re-establish the nominal conditions (water-cooled).</li><li>5. The adjusting valve for the cooling-water flow needs to be re-adjusted - contact a technician for refrigeration plants to have the nominal calibration re-established (water-cooled).</li><li>6. Refrigerant gas leak – contact a technician for refrigeration plants.</li><li>7. Compressor does not work – see specific point.</li></ol>  |
-

12.3 Recommended spare parts

**NOTE:** To order the recommended spare parts or other elements, the data on the name plate must be indicated.

ID N.	DESCRIPTION	PART NUMBER	BB LC & BB LC -R			
			480	600	720	
2	LPS	Pressure switch	XE RA 5655NNN085	1	1	1
4	HPS	Pressure switch	XE RA 5655NNN087	1	1	1
6	MC	Compressor	XE RA 5030340006	1		
			XE RA 5030340008		1	
			XE RA 5030340010			1
7		Hot gas by-pass valve	XE RA 64140SS151	2	2	2
9	MV	Complete fan	XE RA 5250390002	1	1	1
10		Filter drier	XE RA 6650SSN165	1	1	1
12	BT	Temperature probe	XE RA 5625NNN036	4	4	4
17	DMC24	Display module	XE RA 5620100002	1	1	1
		Main module (air cooled)	XE RA 5620100003	1	1	1
		Main module (water cooled)	XE RA 5620100003	1	1	1
		Cable main module to display	XE RA 5625NNN099	1	1	1
19		Water regulating valve (water cooled)	XE RA 64335FF005	1	1	1
21	ELD	BEKOMAT condensate drain	4009684	1	1	1
		BEKOMAT service unit	4008998	1	1	1
22	QS	Main switch	XE RA 5450SZN100	1	1	1
37		Pressure transducer	XE RA 5622NNN002	1	1	1
60	Q1	Circuit breaker	XE RA 54443SM152	1	1	1
	Q1	Auxiliary contact	XE RA 5490CAX060	1	1	1
	FU	Fuse kit	XE RA 5446FSA100	1	1	1
	KC1-KV1-KV2	Contacteur	XE RA 5454TLT016	3	3	3
	KV1-KV2	Mechanical interlock	XE RA 5490INM011	1	1	1
	KHP	Relay	XE RA 5456REL002	1	1	1
	TF	Transformer	XE RA 5440TFM023	1	1	1
RPP	Reverse phase protector	XE RA 5456REL050	1	1	1	

## 12.4 Maintenance works at the refrigeration cycle



### Caution! Refrigerant!

Maintenance and repair works at refrigeration systems must only be carried out by BEKO service technicians in accordance with the local provisions.  
The total amount of refrigerant in the system must be collected for recycling purposes, resource recovery or disposal.

**The refrigerant must not be discharged into the environment.**

When delivered, the chiller is ready to operate and filled with a refrigerant of the R407C type.



Should you detect a refrigerant leak, please contact a BEKO service technician. Prior to any intervention, the room needs to be ventilated.

When the refrigeration cycle needs to be refilled, please also contact a BEKO service technician.  
You will find the refrigerant type and amount on the name plate of the chiller.

Properties of the refrigerant used:

Refrigerant	Chemical formula	MIK	GWP
R407C - HFC	R32/125/134a (23/25/52) CHF <sub>2</sub> CF <sub>3</sub> /CH <sub>2</sub> F <sub>2</sub> /CH <sub>2</sub> FCF <sub>3</sub>	1000 ppm	1653

## 12.5 Dismantling the chiller

When the chiller is dismantled, all parts and operating materials related to the plant need to be disposed of separately.



Part	Material
Refrigerant fluid	R407C, Oil
Canopy and supports	Carbon steel, Epoxy paint
Refrigerating compressor	Steel, Copper, Aluminium, Oil
Heat exchanger	Stainless steel, Copper
Condensate separator	Stainless steel
Condenser unit	Aluminium, Copper, Carbon steel
Pipe	Copper
Fan	Aluminium, Copper, Steel
Valve	Brass, Steel
Electronic level drain	PVC, Aluminium, Steel
Insulation material	Synthetic rubber without CFC, Polystyrene, Polyurethane
Electric cable	Copper, PVC
Electric parts	PVC, Copper, Brass



We recommend observing the safety provisions in force for the disposal of each material type.


The refrigerant contains lubricating-oil droplets which are released by the compressor.

The refrigerant must not be discharged into the environment. It must to be sucked off from the chiller using a suitable device, and then needs to be supplied to a collection point.

### 13 Appendices

#### 13.1 Chiller dimensions

##### 13.1.1 Dimensions BEKOBLIZZ LC 480-720




DMS0461

## 13.2 Exploded diagrams

### 13.2.1 Components of the exploded diagrams

<b>1</b>	Heat exchanger group	<b>22</b>	Main switch
	a – Air-to-refrigerant heat exchanger	<b>36</b>	Liquid separator
	b – Condensate separator	<b>37</b>	Refrigerant pressure transducer
<b>2</b>	Refrigerant pressure switch LPS	<b>51</b>	Front panel
<b>4</b>	Refrigerant pressure switch HPS	<b>52</b>	Back plate
<b>6</b>	Compressor	<b>53</b>	Right sidewall
<b>7</b>	Hot-gas bypass valve	<b>54</b>	Left sidewall
<b>8</b>	Condenser (air-cooled)	<b>55</b>	Cover
<b>9</b>	Condenser fan	<b>56</b>	Base plate
<b>10</b>	Filter dryer	<b>57</b>	Upper plate
<b>11</b>	Capillary tube	<b>58</b>	Carrier support
<b>12</b>	T1 temperature probe (dew point)	<b>59</b>	Support bracket
<b>13</b>	Condensate drain service valve	<b>60</b>	Control panel
<b>17</b>	Air chiller control	<b>65</b>	Condenser filter
<b>18</b>	Condenser (water-cooled)	<b>66</b>	QE door
<b>19</b>	Condenser water-regulating valve (water-cooled)	<b>81</b>	Adhesive label flow chart
<b>20</b>	Refrigerant reservoir (water-cooled)	<b>83</b>	Refrigerant service valve – high pressure
<b>21</b>	BEKOMAT drain	<b>84</b>	Refrigerant service valve – low pressure

13.2.2 Exploded diagram BEKOBLIZZ LC 480-720




**13.3 Electric diagrams**

**13.3.1 Electric diagrams – list of components**

- MC** : Compressor
- MV** : Condenser fan
- DMC24RU** : DMC24 display module – air chiller control
- DMC24MA** : DMC24 main module – air chiller control
- BT1** : T1 Temperature probe – dew point
- BT2** : T2 Temperature probe – air IN
- BT3** : T3 Temperature probe – compressor suction
- BT4** : T4 Temperature probe – compressor discharge
- BHP** : Refrigerant pressure transducer
- HPS** : Pressure switch – compressor discharge side (HIGH PRESSURE)
- LPS** : Pressure switch – compressor suction side (LOW PRESSURE)
- ELD** : BEKOMAT drain
- EVD** : Time-controlled drain (not used)
- QS** : Main switch with locking device
- RC** : Compressor crankcase heater
  
- NT1** : Only air-cooled
- NT2** : Check the transformer connections with regard to the supply voltage
- NT3** : Jump, if not installed
- NT4** : Provided and cabled by the customer
- NT5** : Internal control
- NT6** : Time-controlled drain outlet (not used)
- NT7** : Only water-cooled
  
- BN** = BROWN                      **OR** = ORANGE
- BU** = BLUE                         **RD** = RED
- BK** = BLACK                       **WH** = WHITE
- YG** = YELLOW/GREEN           **WH/BK** = WHITE/BLACK



13.3.3 Electric diagrams BEKOBLIZZ LC 480-720 - Electronic control unit DMC 24 Sheet 2/3



Technical modifications are subject to change without notice; errors not excluded.

Drawing no.: BKBBLC5478QCDD001  
 Rev. 01  
 Note: Sheet 02 of 03

BEKO TECHNOLOGIES GMBH  
 http://www.beko.de



## 14 EC Declaration of Conformity

BEKO TECHNOLOGIES GMBH  
41468 Neuss, GERMANY  
Tel: +49 2131 988-0  
www.beko.de



## EG-Konformitätserklärung

Wir erklären hiermit, dass die nachfolgend bezeichneten Produkte den Anforderungen der einschlägigen Richtlinien und technischen Normen entsprechen. Diese Erklärung bezieht sich nur auf die Produkte in dem Zustand, in dem sie von uns in Verkehr gebracht wurden. Nicht vom Hersteller angebrachte Teile und/oder nachträglich vorgenommene Eingriffe bleiben unberücksichtigt.

Produktbezeichnung:	BEKOBLIZZ
Modelle:	LC 12, 35, 55, 90, 115, 150, 240, 355, 480, 600
Spannungsvarianten:	LC 12 – 355: AC 230 V LC 480 – 600: AC 400 V
Betriebsdruckbereich:	4-15 bar
Produktbeschreibung und Funktion:	Druckluft-Tiefkühlsystem
<b>Maschinen-Richtlinie 2006/42/EG</b>	
Angewandte Normen:	EN 953, EN 1050, EN 1088, EN 12100, EN 13849-1
Name und Anschrift der Person, die bevollmächtigt ist, die technische Dokumentation zusammenzustellen:	Herbert Schlensker Im Taubental 7 41468 Neuss, Deutschland

### Niederspannungs-Richtlinie 2006/95/EG

Angewandte Normen:	EN 60204-1
Anbringungsjahr der CE-Kennzeichnung:	12

### EMV-Richtlinie 2004/108/EG

Angewandte Normen:	EN 50081-2, EN 50082-2
--------------------	------------------------

### Druckgeräte-Richtlinie 97/23/EG

Angewandte Normen:	ASME VIII Div. 1, EN 378-2, EN 10028-3, EN 12451
Angewandtes Konformitätsbewertungsverfahren:	LC 480 – 600: Modul A

LC 12-355: Die Produkte fallen in keine Druckgerätekategorie und sind gemäß Artikel 3 Absatz 3 in Übereinstimmung mit der in den Mitgliedstaaten geltenden guten Ingenieurspraxis ausgelegt und werden dieser entsprechend hergestellt.

### ROHS II-Richtlinie 2011/65/EU

Die Vorschriften der Richtlinie 2011/65/EU zur Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten werden erfüllt.

Neuss, 30.01.2013

BEKO TECHNOLOGIES GMBH

  
i.V. Christian Riedel  
Leiter Qualitätsmanagement

BEKO TECHNOLOGIES GMBH  
41468 Neuss, GERMANY  
Tel: +49 2131 988-0  
www.beko.de



## EG-Konformitätserklärung

Wir erklären hiermit, dass die nachfolgend bezeichneten Produkte den Anforderungen der einschlägigen Richtlinien und technischen Normen entsprechen. Diese Erklärung bezieht sich nur auf die Produkte in dem Zustand, in dem sie von uns in Verkehr gebracht wurden. Nicht vom Hersteller angebrachte Teile und/oder nachträglich vorgenommene Eingriffe bleiben unberücksichtigt.

Produktbezeichnung: BEKOBLIZZ  
Modelle: LC 720  
Betriebsspannung: AC 400 V  
Betriebsdruckbereich: 4-15 bar  
Produktbeschreibung und Funktion: Druckluft-Tiefkühlsystem

### Maschinen-Richtlinie 2006/42/EG

Angewandte Normen: EN 953, EN 1050, EN 1088, EN 12100, EN 13849-1  
Name und Anschrift der Person, die bevollmächtigt ist, die technische Dokumentation zusammenzustellen: Herbert Schlensker  
Im Taubental 7  
41468 Neuss, Deutschland

### Niederspannungs-Richtlinie 2006/95/EG

Angewandte Normen: EN 60204-1  
Anbringungsjahr der CE-Kennzeichnung: 12

### EMV-Richtlinie 2004/108/EG

Angewandte Normen: EN 50081-2, EN 50082-2

### Druckgeräte-Richtlinie 97/23/EG

Angewandte Normen: ASME VIII Div. 1, EN 378-2, EN 10028-3, EN 12451  
Angewandtes Konformitätsbewertungsverfahren: Modul A1  
Benannte Stelle: Royal & Sun Alliance Certification Services  
Manchester, UK

### ROHS II-Richtlinie 2011/65/EU


Die Vorschriften der Richtlinie 2011/65/EU zur Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten werden erfüllt.

Die Produkte sind mit dem abgebildeten Zeichen gekennzeichnet:



Neuss, 11.03.2013

BEKO TECHNOLOGIES GMBH

  
i.V. Christian Riedel  
Leiter Qualitätsmanagement

**BEKO TECHNOLOGIES GMBH**  
 41468 Neuss, GERMANY  
 Tel: +49 2131 988-0  
 www.beko.de



## EC Declaration of Conformity

We hereby declare that the products indicated hereafter, in the delivered performance, comply with the stipulations of the relevant standards. This declaration only refers to products in the condition in which they have been placed into circulation. Parts which have not been installed by the manufacturer and / or modifications which have been implemented subsequently remain unconsidered.

Product designation :	BEKOBLIZZ
Types :	LC 12, 35, 55, 90, 115, 150, 240, 355, 480, 600
Voltage options :	LC 12 – 355 : AC 230 V LC 480 – 600 : AC 400 V
Operating pressure range :	4 – 15 bar
Product description and function :	Compressed air chiller - dryer

### **Machinery Directive 2006/42/EC**

Harmonised standards applied :	EN 953, EN 1050, EN 1088, EN 12100, EN 13849-1
Name and address of the person authorized to compile the technical documentation :	Herbert Schlensker Im Taubental 7 41468 Neuss, Deutschland

### **Low-Voltage Directive 2006/95/EC**

Harmonised standards applied :	EN 60204-1
Year of CE labelling :	12

### **EMC Directive 2004/108/EC**

Harmonised standards applied :	EN 50081-2, EN 50082-2
--------------------------------	------------------------

### **PED Directive 97/23/EC**

Harmonised standards applied :	ASME VIII Div. 1, EN 378-2, EN 10028-3, EN 12451
Applied conformity assessment procedures :	LC 480 – 600 : Modul A

LC 12-355:	The products do not fall into any pressure equipment category and are designed according to Article 3 Paragraph 3, in accordance with the good engineering practice effective in the member states, and are manufactured in compliance with this practice.
------------	--

### **RoHS II Directive 2011/65/EU**

The terms of Directive 2011/65/EU on the Restriction of the use of certain hazardous substances in electrical and electronic devices are fulfilled.

Neuss, 30.01.2013

**BEKO TECHNOLOGIES GMBH**

p.p. Christian Riedel  
Quality Manager

BEKO TECHNOLOGIES GMBH  
41468 Neuss, GERMANY  
Tel: +49 2131 988-0  
www.beko.de



## EC Declaration of Conformity

We hereby declare that the products indicated hereafter, in the delivered performance, comply with the stipulations of the relevant standards. This declaration only refers to products in the condition in which they have been placed into circulation. Parts which have not been installed by the manufacturer and / or modifications which have been implemented subsequently remain unconsidered.

Product designation : BEKOBLIZZ  
Types : LC 720  
Voltage options : AC 400 V  
Operating pressure range : 4-15 bar  
Product description and function : Compressed air chiller - dryer

### Machinery Directive 2006/42/EC

Harmonised standards applied : EN 953, EN 1050, EN 1088, EN 12100, EN 13849-1  
Name and address of the person authorized to compile the technical documentation : Herbert Schlensker  
Im Taubental 7  
41468 Neuss, Deutschland

### Low-Voltage Directive 2006/95/EC

Harmonised standards applied : EN 60204-1  
Year of CE labelling : 12

### EMC Directive 2004/108/EC

Harmonised standards applied : EN 50081-2, EN 50082-2

### PED Directive 97/23/EC

Harmonised standards applied : ASME VIII Div. 1, EN 378-2, EN 10028-3, EN 12451  
Applied conformity assessment procedures : Modul A1  
Notified Body : Royal & Sun Alliance Certification Services  
Manchester, UK

### RoHS II Directive 2011/65/EU

The terms of Directive 2011/65/EU on the Restriction of the use of certain hazardous substances in electrical and electronic devices are fulfilled.

These products are labelled with the following mark :



Neuss, 11.03.2013

BEKO TECHNOLOGIES GMBH

p.p. Christian Riedel  
Quality Manager



**Headquarter Deutschland / Germany**

BEKO TECHNOLOGIES GMBH  
Im Taubental 7  
D - 41468 Neuss  
Tel. +49 2131 988 0  
Mobil +49 / (0) 174 / 376 03 13  
beko@beko-technologies.de

**Benelux**

BEKO TECHNOLOGIES B.V.  
Veenen 12  
NL - 4703 RB Roosendaal Tel. +31 165  
320 300  
benelux@beko-technologies.com

**España / Spain**

BEKO Tecnológica España S.L. Torruella i  
Urpina 37-42, nave 6 E - 08758 Cervelló  
Tel. +34 93 632 76 68  
Mobil +34 610 780 639  
info.es@beko-technologies.es

**Italia / Italy**

BEKO TECHNOLOGIES S.r.l  
Via Peano 86/88  
I - 10040 Leini (TO)  
Tel. +39 011 4500 576  
Fax +39 0114 500 578  
info.it@beko-technologies.com

**South East Asia**

BEKO TECHNOLOGIES S.E.Asia  
(Thailand) Ltd.  
75/323 Soi Romklao, Romklao Road  
Sansab Minburi  
Bangkok 10510  
Tel. +66 2-918-2477  
info.th@beko-technologies.com

**United Kingdom**

BEKO TECHNOLOGIES LTD.  
Unit 11-12 Moons Park  
Burnt Meadow Road  
North Moons Moat  
Redditch, Worcs, B98 9PA  
Tel. +44 1527 575 778  
info@beko-technologies.co.uk

**中华人民共和国 / China**

BEKO TECHNOLOGIES (Shanghai)  
Co. Ltd.  
Rm. 606 Tomson Commercial Building 710  
Dongfang Rd.  
Pudong Shanghai China P.C. 200122  
Tel. +86 21 508 158 85  
info.cn@beko-technologies.cn

**中華人民共和國香港特別行政區 /**

**Hong Kong SAR of China**  
BEKO TECHNOLOGIES LIMITED  
Unit 1010 Miramar Tower 132 Nathan Rd.  
Tsim Sha Tsui Kowloon Hong Kong Tel.  
+852 5578 6681 (Hong Kong)  
Tel. +86 147 1537 0081 (China)  
tim.chan@beko-technologies.com

**日本 / Japan**

BEKO TECHNOLOGIES K.K  
KEIHIN THINK Building 8 Floor 1-1  
Minamiwatarida-machi Kawasaki-ku,  
Kawasaki-shi  
JP - 210-0855  
Tel. +81 44 328 76 01  
info@beko-technologies.jp

**臺灣 / Taiwan**

BEKO TECHNOLOGIES Co.,Ltd 16F.-5  
No.79 Sec.1  
Xintai 5th Rd., Xizhi City New Taipei City  
221 Taiwan (R.O.C.)  
Tel. +886 2 8698 3998  
info.tw@beko-technologies.tw

**France**

BEKO TECHNOLOGIES S.à.r.l.  
Zone Industrielle  
1 Rue des Frères Rémy F - 57200  
Sarreguemines Tél. +33 387 283 800  
info@beko-technologies.fr

**Česká Republika / Czech Republic**

BEKO TECHNOLOGIES s.r.o.  
Na Pankraci 58  
CZ - 140 00 Praha 4  
Tel. +420 24 14 14 717 /  
+420 24 14 09 333  
Mobil +420 605 274 743  
info@beko-technologies.cz

**India**

BEKO COMPRESSED AIR  
TECHNOLOGIES Pvt. Ltd.  
Plot No.43/1 CIEEP Gandhi Nagar  
Balanagar Hyderabad  
IN - 500 037  
Tel +91 40 23080275 / +91 40 23081107  
madhusudan.masur@bekoindia.com

**Polska / Poland**

BEKO TECHNOLOGIES Sp. z o.o.  
ul. Pańska 73  
PL - 00-834 Warszawa Tel. +48 22 314 75  
40  
Mobil +49 173 28 90 700  
info.pl@beko-technologies.pl

**USA**

BEKO TECHNOLOGIES CORP.  
900 Great Southwest Pkwy SW  
US - Atlanta,  
GA 30336  
Tel. +1 404 924-6900  
Fax +1 (404) 629-6666  
beko@bekousa.com

Original operating instructions in English.

Subject to technical changes / errors excepted.

BEKOBLIZZ\_LC\_480-720\_manual\_en\_2012\_09.doc